AURA" WHEELWELL

INSTALLATION GUIDE

MAIN COMPONENTS



OPT7

INSTALLATION



STEP 1

Decide where to locate the light strips and ensure wiring has enough length for control box to be installed in desired location.

As shown below, connect all light strips to the control box with the included extension cables.



- 1. Connecting to more than 10 AMP will override the kit and cause early failure, ensure it is 10AMPs or less!!
- WARNING
- 2. Please ensure that the LED bars or strips/control box/wiring all are mounted in areas where will not exceed 85°C or 185°F.

INSTALLATION





STEP 2

Secure Control box in desired location with Velcro or zipties.

* CONTROL BOX NOT WATERPROOF Ensure the control box is safely and securely hidden from exposing elements of moisture.

STEP 3

Secure the light strips using the zip ties to tie all the wiring away from the moving components.





STEP 4

Using the included E-Z Remote, select your desired color or pattern.

- 1 Power-ON
- 2 Automatic Color Change
- 3 Power-OFF
- 4 Speed +/- 8 Levels
- 5 Mode +/- 19 Mode
- 6 Dimmer 8 Levels
- 7 Color Selection 12 Colors

DISCLAIMER

OPT7 Lighting is not liable for damages or personal injuries while installing this product. The Installation Guide is intended as assistance to reduce setup time. OPT7 Lighting assumes no responsibility for improper installation.

If you are unfamiliar with your vehicle or inexperienced with aftermarket upgrades, please seek professional assistance.

OPT7 recommends installation for safety and guidance.

Modified installations or installation recommendations not specified by OPT7 Lighting will void product warranty.