


For OPT7 GLOW DREAMCOLOR SERIES

CONTROL BOX PIXEL SETTING GUIDE



OPT7 GLOW DREAMCOLOR Control Box with Sound Sync




OPT7 GLOW DREAMCOLOR Control Box without Sound Sync



HOW TO SET PIXEL

<		My ligh	nt		
R 98 G 0 B 255		0			
	+	+		+	+
Brighti 🌣 🛑	ness:100) 🔅
٩	Adjust	Rhythm	↓ ↓ Mode	Scenes	More

<		
My light		>
Create Group		>
Menu Style	Default	>
Mode Style	Default	>
Wires Order		>
Pixel Setting		>
Collapse Mode	Open	>
Custom Functions		>
Remove Device		



STEP 1

Ensure that the control box is properly connected then Click the icon 2 to enter Product Settings.

STEP 2

Click Pixel Setting to access the configuration.

STEP3

Refer to the table below for the corresponding pixel values of the OPT7 product. Enter the correct values to ensure proper functionality.

IMPORTANT

*Verify that the control box is correctly set up and connected to the app when setting the conrol box pixel


*Only Dreamcolor series products require pixel adjustments.

*Make sure to enter the correct pixel values corresponding to your product.

*Incorrect values may cause the product to malfunction.

*After setting the pixel, remember to pair the remote control.

OPT7 GLOW DREAMCOLOR **SERIES**



DISCLAMER

OPT7 Lighting is not liable for damages or personal injuries while installing this product. The Installation Guide is intended as assistance to reduce setup time. OPT7 Lighting assumes no responsibility for improper installation. If you are unfamiliar with your vehicle or inexperienced with aftermarket upgrades, please seek professional assistance.

OPT7 recommends installation for safety and guidance. Modified installations or installation recommendations not specified by OPT7 Lighting will void product warranty.