

AURA™

DOUBLE ROW


INTERIOR

INSTALLATION GUIDE


MAIN COMPONENTS




LED STRIPS




MOUNTING KIT




CONTROL BOX



HAND HELD REMOTE




EXTENSION WIRES



CIGARETTE LIGHTER POWER ADAPTER

INSTALLATION




STEP 1

Determine where to locate the light strips and ensure wiring has enough length for control box to be installed in desired location.

IMPORTANT:

* CONTROL BOX NOT WATERPROOF
Ensure the control box is safely and securely hidden from exposing elements of moisture.

As shown below, connect all light strips to the control box with the included extension wires.




WARNING


1. Connecting to more than 10 AMP will override the kit and cause early failure, ensure it is 10 AMP or less!!
2. Please ensure that the LED bars or strips/control box/wiring all are mounted in areas where will not exceed 85°C or 185°F.

Once connected, plug the control box with Cigarette Lighter Power Adapter into an available 12 volt charging port.

12 VOLT CHARGING PORT CIGARETTE LIGHTER POWER ADAPTER




INSTALLATION



STEP 2

Secure control box in desired location with Velcro or zip ties.


*** CONTROL BOX NOT WATERPROOF**
Ensure the control box is safely and securely hidden from exposing elements of moisture.



STEP 3

Thoroughly clean the surface where you plan on mounting the LED strip with rubbing / isopropyl alcohol. Tear the double-sided tape and firmly press the LED strip to the mounting area and hold for 3 seconds. Then use the zip ties to tie all wiring away from moving components.


WARNING!



Note the
direction of
the arrows

**CORRECT
INSTALLATION**

**PRODUCT WARRANTY WILL BE VOID
FOR IMPROPER INSTALL.**




STEP 4

Using the included 21Key E-Z Remote, select your desired color or pattern.

- | | |
|---|-------------------------------------|
| 1 | Power-ON |
| 2 | Automatic Color Change |
| 3 | Power-OFF |
| 4 | Speed +/- 10 Levels |
| 5 | Mode +/- 24 Modes |
| 6 | Dimmer 10 Levels |
| 7 | Color Selection 9 Colors |
| 8 | Sound Sync Color Selection 3 Colors |

NOTE: When you use this product, stay within 10m/33ft from the control box.



HOW TO PAIR THE REMOTE?

Pair the Device:

To pair the remote, reconnect the power, then aim the remote at the control box and hold the ON button until the LED strips flash white.

Unpair the Device:

To unpair the remote, reconnect the power, then aim the remote at the control box and hold the OFF button until the LED strips flash white.

DISCLAIMER

OPT7 Lighting is not liable for damages or personal injuries while installing this product. The Installation Guide is intended as assistance to reduce setup time. OPT7 Lighting assumes no responsibility for improper installation. If you are unfamiliar with your vehicle or inexperienced with aftermarket upgrades, please seek professional assistance.

OPT7 recommends installation for safety and guidance.

Modified installations or installation recommendations not specified by OPT7 Lighting will void product warranty.