


FULL-SIZE REMOTE CONTROL BUTTON LAYOUT



- 1 ON & OFF**
 - Only control "RGB" light
- 2 Dimmer +/-**
 - Brightness Setting: 50 Levels
- 3 Color Selector**
 - 20 different solid modes
- 4 Independent Control Of White Light**
 - ON & OFF
 - Dimmer +/-
 - Brightness Setting: 50 Levels
 - Default brightness
 - Brightness Setting: 4 Levels
- 5 Style Mode**
 - 3 Color Cycle
 - Default 3 color variations (Random)
 - Supports brightness and speed adjustment
 - 3 Fade
 - Default 3 color variations (Random)
 - Supports speed adjustment
 - 7 Color Cycle
 - Default 7 color variations (Random)
 - Supports brightness and speed adjustment
 - Beat/SoundSYNC
 - Default 20 color variations (Random)
 - Supports brightness adjustment
 - Strobe
 - Default 20 color variations (Random)
 - Supports brightness and speed adjustment
 - AUTO
 - Play all dynamic style modes
- 6 Quick/Slow**
 - Speed Setting : 10 Levels

SPECIFICATIONS

Wattage

8W Per Pod

Amp Draw

8A

8 LEDs

Quad-Core CREE

Brightness

1,600 Lumens Per Pod

Voltage

12V

Resistance

IP68 Water-Resistant (Pod Only)

Operating Temperature

-20°-150°F

DISCLAIMER


OPT7 Lighting is not liable for damages or personal injuries while installing this product. The Installation Guide is intended as assistance to reduce setup time. OPT7 Lighting assumes no responsibility for improper installation. If you are unfamiliar with your vehicle or inexperienced with aftermarket upgrades, please seek professional assistance.

2 YEAR WARRANTY


OPT7[®]

QUANTUM ROCK LIGHTS


INSTALL GUIDE




Quantum Rock Light Pod **x4**




Rubber Pad **x4**



12V Constant Power Wire **x1**




Full-Size Remote **x1**




Fuse Tap (3 different sizes) **x1**



10ft Extension Cable **x6**




Metal Screw **x8**



Control Box **x1**

WHERE TO INSTALL

RECOMMENDED LOCATIONS FOR ROCK LIGHT PODS



INSTALLATION STEPS

TOOLS REQUIRED

- 5/32-inch Drill Bit
- 7/64-inch Drill Bit
- Phillips Head Screwdriver

1. Designate your mounting locations for each Rock Light Pod and the control box. (Refer to page 2 for recommended mounting locations)

Avoid hot surfaces and/or moving parts.

2. Use a pen to mark the holes where you want to mount the Rock Light Pods. Then, drill a 5/32" hole(s) for the wire connector to pass through.
3. Drill a 7/64" hole for each marked hole.
4. Secure the Rock Light Pods using the included screws. (If mounting on a rounded or uneven surface, utilize the optional rubber mounting pads.)

Caution: Rock Light Pods become extremely hot during use - keep away from any vehicle parts that may be damaged by exposure to high temperatures.

5. Connect all Rock Light Pod lines to the control box connectors. Secure by twisting.
6. Connect the red positive line from the control box directly to the vehicle battery.
7. Ground the negative wire from the control box by connecting it to an unpainted area on your vehicle's frame.
8. Using a fuse tap, connect the 12V control wire from the control box to a power source that turns on ONLY when the key is turned to ACC/ON or a switched fuse position.

Some examples of these power sources are: radio, dome light or those that are marked as accessory in your owner's manual or on your fuse box cover diagram.

The kit will not function without this connection.

If you are uncomfortable performing work of this nature yourself, then do not hesitate to consult a professional for help. Working with a vehicle's electrical system can be hazardous to an unqualified individual. OPT7 is not liable for damages or personal injuries while installing this product. The installation guide is provided as assistance to reduce set up time.